

FWH FIREWALL HANGER

THE ONLY TESTED HANGER FOR COMPLETE INSTALLATION BEFORE THE DRYWALL IS ATTACHED

- ➔ The industry's best labor-saving solution for attaching floor framing to 2-hour fire-rated walls in wood frame construction.
- ➔ No framing follow-up required.
- ➔ Simple. Effective. Lower installed costs.
- ➔ Skewed options up to 45 degrees.

INSTALL BEFORE DRYWALL IS ATTACHED.

THE ONLY HANGER TESTED TO ASTM E814

Approved to penetrate a 2-hour fire rated wall system.

ICC-ES 3444

FL 17241

LA City RR25749

DESIGNED TO SUPPORT OPEN WEB TRUSSES, ENGINEERED WOOD AND SOLID SAWN JOISTS

INSTALL WITH NAILS

Top flanges are fastened with (6) 10d common nails to top plate.

SPIRAL CUTTER TEMPLATE (FWH-T)

Drywall Cut-Out Tool. Slide the drywall into position and fasten to the framing members.

DIRECT LOAD TRANSFER TO THE TOP OF THE FRAMED WALL

Published loads supported without drywall in place. No additional connectors required to offset overturning of plate.

SUPERIOR DESIGN VALUES COMPARED TO THE COMPETITION

DRIVING POINT

Mark slot location on drywall without measuring.

MiTek®

1-800-268-3434

MiTek.ca

